Packard Bell



MODEL
PB 61248

Slimline Scanner

USB Scanner Installation Guide

E

1 Unpacking the Scanner

Unpack the package and inspect the items closely to make sure no item is damaged.

The package should include:

- The Scanner
- Power Adapter
- USB Scanner Installation Guide
- Installation CD
- Scanning Utilities Manual (either included in the Installation CD or printed separately)

2 Driver Installation

NOTE: Please complete the driver installation before installing the Scanner. Do not connect the power adapter to the scanner at this stage.

1. Insert the Driver Installation CD into your disk drive. (Proceed toSection 4.)

2. Click on '**Start**' and select '**Run**'. (If Autorun function disabled.)



3. In the '**Run**' dialog box, type '*drive*:\run' where *drive* is your CD-ROM drive and click '**OK**.'

4. Follow all on-screen instructions.

NOTE: When you are presented with the option of restarting Windows after completing the driver installation please choose '**OK**'.

3 The Scanner Parts



4 Connecting the Scanner to the PC

Refer to the following illustration and steps to connect your scanner.

1. With the power to your PC on, connect the scanner's USB cable to the USB port of your PC.
2. Connect the power adapter to the Scanner and plug it into an appropriate power outlet.

Upon connecting the power adapter, the Windows operating system will automatically detect your scanner and update your system configuration.



4A If Add New Hardware Wizard Appears (For Windows 98 Users)

NOTE: The **Add New Hardware Wizard** will not appear if you have already installed your scanner software. If software is installed and NO **Add New Hardware Wizard** dialog box appears, please proceed with the **NOTE** below and section 5, Using the Scanner.

If the **Add New Hardware Wizard** dialog box appears upon installing the software driver and connecting the power adapter, perform the following steps:

1. Click on the '**Next**' button when the Add New Hardware Wizard dialog box appears. (See box on right.)
2. Select below option to search for your computer drivers; then click '**Next.**'




Add New Hardware Wizard
This wizard searches for new drivers for:
Unknown Device
A device driver is a software program that makes a hardware device work.
Next >
Cancel

3. Check box at '**Specify a Location**' and then click '**Browse.**'
4. Select '**CD ROM**' in 'Browse for Folder' dialog box and then select the '**Win 98**' folder. After selecting, click '**OK.**'
5. Click '**Next**' and the following installation message will appear, '**Windows is now ready to install the best driver for this device...**' When this message appears, click '**Next.**'
6. Click the '**Finish**' button to exit.

NOTE: Since your scanner model is equipped with a Cover Sensor, upon raising the cover of your scanner you will be given a choice of whether to use the Scan Dialog box (refer to the Scanning Utilities Manual) that came with your scanner or to use the Imaging program (refer to your Windows 98 reference guide) that is built into your Windows 98 operating system.

5 Using the Scanner

There are two separate methods to scan an image, the Scan Dialog box and the TWAIN Dialog box. Refer to the Scanning Utilities Manual for a description of these to facilitate your use of the scanner; or refer to the on-line manual and help system any time when using the scanner software. This easy-to-use system contains detailed information about the scanner topics and its functions.

E

5A To access the Scan Dialog box, you can do any of the following:

1. **The Cover Sensor**: Simply lift the cover and begin scanning. This scanner is equipped with a Cover Sensor feature that automatically opens the Scan Dialog box,
   or
2. **The Direct Scan Icon**: Double-click the Direct Scan icon, located in your Windows taskbar,

   or
3. **The Scan Dialog Box Item**: Click on '**Start**' on your Windows desktop and locate the name of your scanner model under '**Programs**'. Then double-click the item '**Scan Dialog Box**'.

5B To access the TWAIN Dialog box, you can do the following:

1. Launch the TWAIN-compliant program (e.g. Photo Express).
2. Under the File menu open the **Acquire** command and choose **Scanner** OR Click the Scanner icon.
   The Select Data Source dialog box appears.
3. Choose your scanner model from the list.
4. Click on the '**Acquire**' button.
   The Select Data Source dialog box closes.
   The TWAIN Dialog box appears.





5C To access the on-line manual:

1. Click on '**Start**' and select '**Programs**'.
2. Click on your scanner model and select '**Scanner's User's Guide**'.

6 Driver Installation (iMac)

NOTE: Please complete the driver installation before installing the Scanner. Do not connect the power adapter to the scanner at this stage.

1. Insert the Driver Installation CD into your disk drive.
2. Wait for the **Installer** icon to appear on your desktop.

3. Double-click on the **Installer** icon to open the **Installer** dialog box.

4. Double-click on the **Install** icon.
5. Continue to follow all on-screen instructions to complete the driver installation.

6A Connecting the Scanner to the iMac

Refer to the following steps to connect your scanner.

1. With the power to your iMac on, connect the scanner's USB cable to the USB port of your iMac.
2. Connect the power adapter to the Scanner and plug it into an appropriate power outlet.

7 Specifications

Scanner Type	Color Flatbed
Scan Area	21.6 cm x 29.7 cm (8.5" x 11.7")
Scan Modes:	
True Color	36-bit, 68.7 billion colors
	48-bit (software enhanced)
Gray Mode	12-bit, 4096 shades of gray
Text/Line Art	1 bit/pixel (2 levels)
Scan Method	Single Pass Scanning
Resolution Control:	
Optical	600dpi (H) x 1200dpi (V)
Enhanced	19200dpi x 19200dpi (software controlled)
Scanning Data Buffer	32KB (maximum)
Power Consumption	9.6 Watt (12V DC)
Operating Temperature	10°C ~ 40°C (50°F ~ 104°F)
Operating Humidity	35% ~ 80% RH, Non-Condensing
Storage Temperature	-10°C ~ 60°C (14°F ~ 140°F)
Storage Humidity	20% ~ 80% RH, Non-Condensing
Dimensions:	410 x 268 x 36 mm
	16.1 x 10.6 x 1.4 inches (L x W x H)
Weight:	1.9 Kg (4.20 Lbs.)

E

HELPLINE

In the unlikely event that technical advice is required to install this product or in the operation of this product simply call **0870 0132017**

HELPLINE
0870 0132017

P/N: 82-063-00031